

# EASY CLEAN Algae AD

**A Highly Concentrated Wash Tank Additive for use with the Colenta Easy Clean Algae Pump System or Similar**

**Helps Keep Processor Wash Tanks and Rollers Clean and Free from Algae Bio-Slime**



**Stops the Formation and Re-formation of Sludge and Bio-Slime in Wash tanks and on Wash Rack Rollers.**

**Rapid Cleaning Agents Remove Algae Slime & Sludge With water softening agents to keep wash tanks scale free**

**Easy Clean Algae AD: Safe, Non-Toxic, Non-Corrosive, Bio-Degradable**

A highly concentrated, blend of unique cleaning agents. Rapidly breaks down the bio-film which causes slimy, clogging bio-slime. Regular use keeps wash/rinse water clean and fresh.

Safe for use in all NDT and X-Ray Processors, Photographic Film and Paper Processors and in Ultrasonic, Inspection and Static Tanks.

Proven safe. **Easy Clean Algae AD** will not cause film or print instability and is left in the tanks during processing. No need to drain before use.

**1. Automatic Dosing:** For use through the **Colenta Easy Clean Algae Pump System**. Our dosing system automatically doses **Easy Clean Algae AD** into the wash water supplying the wash tank. This keeps the entire wash water system including tank, overflow, pipes and drains spotlessly clean 24/7. Eliminates the option of hand dosing and its required manual procedures. For full details on the **Pump System** please see the separate data sheet.

**2. Manual Dosing:** **Easy Clean Algae AD** can also be used without the **Pump System** to hand dose wash tanks. Add 25ml daily to each 50 litres wash water.

**3. Static, Inspection and Ultra Sonic Tanks.** 1 litre treats up to 1,000 litres water. Added to clean water to stop slime build-up.

**STOPS!**  
Bio-Slime Problems in Wash/Static Tanks

**STOPS!**  
Expensive Downtime

**STOPS!**  
Hand Washing

**STOPS!**  
Slippage & Jamming of Rollers

**STOPS!**  
Blocked Overflow & Flooding