

EASY CLEAN SYSTEM

Developer Tank System Cleaner

2 Part Cleaning solution + Neutraliser

The efficient solution to Remove Chemically Bonded Silver / Emulsion on Developer Tank and Roller surfaces.



Suitable for the many types of Film, Plate and Paper Processors in the PCB/NDT/Medical X-Ray/Photo/Print industries.

Fast Acting – Non Fuming

Easy Clean SYSTEM efficiently removes chemically bonded silver and developer from developer racks, rollers, tanks and pipe-work in approximately 45 minutes to 1 hour

Easy Clean SYSTEM also removes silver build-up from wash / stabiliser racks and tanks.

Note: Do Not Use Easy Clean SYSTEM to clean fix racks or tanks.

Powerful Fast Acting Cleaner

Easy Clean SYSTEM starts to work on contact. Cleaning is both fast and easy.

The rack can be cleaned separately from the processor, however if **Easy Clean SYSTEM** is used with the developer rack left in the tank, this greatly improves the working efficiency of your processor by cleaning the developer tank pipe-work and pumps.

Using **Easy Clean SYSTEM** eliminates fresh chemistry from being contaminated by old chemical build-up on racks and tanks thereby improving the efficiency and life of your developer.

Important Notice

Full instructions for dilution and method of use for Colenta Easy Clean SYSTEM is enclosed with the product.

Pack Size

Each 6x1 litre pack of **Easy Clean System** cleaner contains 2 litres **Part A**, 2 litres **Part B** Cleaning solutions and 2 litres **Part C** Neutraliser.

Dilution

With a dilution of 1:10 each pack makes up to 40 litres working solution.